Coking.com[®]

Using Acoustic Emission Testing to inspect Coke Drums

Presented by: Bobby Wright

Calgary, Canada September 14 - 17, 2009



Objectives

Present basic principles and applications of acoustic emission testing (AET) when used to help assess the reliability and structural integrity of coke drums and overhead vapor piping components, while in service, out of service, and during fabrication.





- Acoustic emission testing handbook
- www.asnt.org



Coking.com[®]

Chapter 4 is dedicated to AE testing of Coke Drums.

Why don't we start with definitions ?

- Reliability....
- Acoustic emission testing....



What is Reliability?

 "Reliability is defined as the probability of an item to perform a required function under specified conditions for a certain period of time."

From University of Maryland Web Site



Acoustic Emission (AE) is...


<u>ASTM E 610</u>

- ...the class of phenomena whereby transient elastic waves are generated by rapid release of energy from localized sources within a material, or the transient elastic waves so generated.
- <u>ASNT</u>
- ...the elastic energy that is <u>spontaneously</u> released by materials when they undergo deformation.



How does AET work?

Principles Description Instrumentation Advantages Limitations Standards






Measurement Chain

Acoustic Emission (AE) Process

- 1. Stimuli Global Source of energy, often mechanical load; other examples: thermal gradient, Hoop stress, etc.
- 2. AE Source localized stress release
- **3.** Wave Propagation dynamic response of structure to AE source
- 4. AE Sensor conversion of mechanical wave to voltage

5. Signal Processing –

- Preamplifier
- Main/System Amplifier
- Amplification and Filtering Functions




Acoustic Emissions are transient elastic waves generated by the rapid release of energy from localized sources within a material.

(Excerpted from ASTM E610-82)

Coking.com[®]

Frequency Regimes






AE principles There are primarily 2 types of AE from "flawed" metals:

- AE type I Associated with plastic deformation (yielding) near stress risers
- AE type II Associated with actual damage progression/crack propagation






Coking.com°

- Type I AE is used as a global screening of components, using pressure or thermal gradients to find stress risers/cracks by imposing a level of stress slightly above normal stress levels.
- Example: In-service over-pressurization of a column or reactor to 110% of maximum operating pressure over last 12 months.



AE type I comes from elastic deformation/yielding !



No load = No AET signals

UNDER LOAD + CRACK FREE MATERIAL = NO AET SIGNALS

UNDER LOAD + CRACKED MATERIAL = AET SIGNALS



- Type II AE is used to monitor and/or detect unknown/existing crack-like flaws in components, which cannot be easily overstressed. AE signals come from actual damage progression or crack propagation.
- Example: On-line monitoring of coke drums for thermally induced fatigue cracks.



AE type II...comes from crack propagation !



Thermally induced fatigue crack in circ. weld of a coke drum

Don't need AE to find that...

...but crack had been growing for a while.

Coking.com[®]

Advantages of AET

- Inspect 100% of the coke drum (global inspection)
- Detect growing cracks, significant to the drum's structural integrity
- Can be applied in-service
- No need to remove insulation
- Wide temperature range (Cryogenic to High temperature)
- Recognized by several standards
- Compliance with local, state & federal regulations
- Significant savings by avoiding vessel entry
- Repeatability / Kaiser Effect

Coking.com®

Limitations of AET

- ... ,
- res
- The mor
- 5%
- In the , ..
- //!
- •
- •
- •



OK,limitations of AET

- Requires experienced and skilled operator
- Qualitative results (can't size defects)
- Fairly complex and expensive hardware/software
- Needs access to circ. Welds via scaffolding or rope
- Requires client/user to be well educated in topic (that's why I am here....)
- Can't find inactive flaws or old cracks. Only active ones.



AET Instrumentation

304 Stainless Steel waveguide and 150kHz sensor



Vallen Digital System TÜF Certified








Four drums Covered with 56 AET probes each Use of waveguide avoids damaging of transducers. Loss of 8dB at contact point is known and compensated for





AET applied to coke drums





Section II

Our experience with Acoustic Emission inspection during acceptance hydrotest of new coke drums

- Sumitomo Japan: Four (two 3%Cr) new drums for Citgo Refinery
- JSW Japan: Four 2¼ Cr 1Mo new drums for Citgo Refinery
- Lyondell-Citgo Refinery: Four new CS drums for LCR



Why AET during initial hydrotest?

- To detect fabrication discontinuities, which are acceptable by Code, but are "active" at stress levels above Code Hoop Stresses.
- These are the flaws, which will eventually initiate and grow thermal fatigue cracks.
- This is the best time to repair fabrication discontinuities, and get drum Code Stamped by A.I.



Code AE hydrotest of new coke drums - 1st 3% Cr shell

(Code Max. Press. Modified to reach past 1 1/2 Design to find smallest defect possible)






AET results

- From all Japanese built coke drums I have personally inspected via AET during hydro (8)@ 2.5 x design pressure, only one fabrication flaw detected and confirmed (repaired) on 1 drum.
- From all non-Japanese built coke drums I have personally inspected via AET during normal 1.5 design pressure hydro (10), they averaged 23 fabrication flaws detected and confirmed (not all repaired).



AET results




Sumitomo UT inspectors checking AET indication




Team from Sumitomo, and Citgo Petroleum



Code AE hydrotest of new coke drums – SES' designed skirt attachment for JSW built drums for Citgo Petroleum









Coking.com[®]

Section III In-service monitoring of coke drums







Typical AE transducer distribution



How do they fail...



Thermally induced fatigue mechanism

Designed as Div.1 vessels, without fatigue considerations

Costly S/D if throughwall cracks develop

AE used to map cracks, often with SG's and TC's.




Sample of our experience with Coke Drums In-Service Acoustic Emission/TC/Inspection

- Petrobras Brazil, Cubatao, Sao Paulo : 4 drums, 1985 •
- Petrocanada Edmonton, Canada: 2 drums, 1988
- Arco Los Angeles: 4 drums, 1990
- Frontier Refinery: 2 drums 1990
- Chevron El Segundo: 6 drums, 1994
- Amoco Whiting: 4 drums, 1994
- Citgo Lake Charles: 4 drums (Coker I), 1990
- Citgo Lake Charles: 4 drums (Coker II), 1995
- Citgo Corpus Christi: 4 drums, 1993
- Lyondell-Citgo Refinery, TX: 4 drums (Coker I), 1995
- Lyondell-Citgo refinery, TX: 4 drums (Coker II), 1996
- Conoco Ponca City: 2 drums 1998
- Conoco Lake Charles: 2 drums 1999
- Chevron El Segundo, CA: 2 drums 2002
- Exxon-Mobil Beaumont, TX: 1 drum 2003
- Valero Refinery, LA: 4 drums 2004
- Suncor, FMM AB- 4 drums 2005

- PDVSa Venezuela 4 Coke overhead systems 2006
- ENAP Chile 2 Coke drums 2007
- Petrobrazi Romania 2 Coke drums 2008



Why drums crack?



Coking.com[®]

In-service acoustic emission inspection of coke drums


- Performed while in-service during regular operations.
- Uses stresses developing during thermal transients at quench and heat-up
- It relies on detecting <u>actual crack growth</u> due to thermal fatigue.
- Since cycles can be substantially different from each other, 3+ cycles are required to screen the drum.



In-service acoustic emission inspection of coke drums (cont.)

- AET can separate ID from OD connected flaws by means of determining when in the cycle, crack growth occurred
- It provides full coverage of the shell, head and cone, or partial coverage focusing on known problem areas (bulges, skirt, nozzles, etc.)







Case history 1

- Cracked skirt attachment weld
- Cracks in "key hole" slots
- Client need to know if and when skirt cracks are growing
- AE needs to separate AET signals from these 2 elevations (9" apart)










Coking.com[®]




Coking.com[®]

40

Case history 2

- In-service monitoring of coke drum for 6 cycles.
- Rare design with top derrick supported by top head by means of a cylindrical skirt.
- Significant cracking found at top skirt-tohead attachment welds
- Difficult location to inspect, not planned.








Case study 3

- Owner wanted to investigate consequences of reducing heat-up time from 3 hr to 45 minutes
- AET and strain gages were used to measure short term (immediate) consequences
- Results indicated no significant changes on AET activity level and strain magnitudes (not a long term assessment)





US West Coast refinery Wanted to know what would Happen if "heat-up" times Were shortened by 2 hrs. AET and SG indicated No significant damage being Caused by operational change


Shell thermocouples only

Coking.com[®]

Case Study 4

- AET on-line monitoring of top head after drill stem dropped.
- Crack located by AET, and monitored for further growth for 3 weeks, until outage allowed repairs





Votion VisualAE™ by Values Santama CentiH is learned to Strate Endmonthe Santama Inc. Houston Tazas, USA

Coking.com[®]

46

Case study 5

- New coker unit with severe vibration issues causing mechanically induced fatigue cracks on overhead vapor lines and nozzles, and foam injection piping.
- Three through-wall failures prior to AET monitoring activation on August 2006.
- AET continuous monitoring have warned of other cracks, which were promptly repaired between cycles. No other failure as of today.
- SES is currently installing mechanical remediation to reduce vibration.




Four coker unit






Overhead piping system in Coker Unit subjected to vibration induced fatigue cracking







Coking.com[®]

Conclusions

- Acoustic emission inspection can screen existing or new coke drums to detect and locate existing crack-like or significant flaws
- It can have a positive impact on T/A planning and budget by reducing and optimizing NDT efforts
- It can predict failure locations, therefore avoid costly shutdowns



Conclusions (cont.)

- Plants need to maintain critical units operational, despite presence of significant flaws.
- There is a wide array of NDE methods available to plant owners/operators to help achieve that objective.
- On some cases AET can provide the necessary information and data to allow for safe continued operation until other actions can be implemented.



Bobby Wright Stress Engineering Services, Inc. Houston, Texas – USA <u>bobby.wright@stress.com</u> (281) 955 2900

